


## CC-Dr. Schutz GmbH

Steinbrinksweg 30  
D-31840  
Hessisch Oldendorf  
Fax: +49-(0)5152-9779-30  
Tel: +49-(0) 5152-9779-0  
info@dr-schutz.com  
www.dr-schutz.com

Dr. Schutz UK Ltd.  
Unit 24, Anglo Business Park  
Smeaton close Aylesbury Bucks HP19 8UP  
Great Britain  
Fax: 01296-334 219  
Tel: 01296-437 827  
steve@dr-schutz.com  
www.dr-schutz.com

## Product-Information



## Floor Shine

### 1. Product Description

Shiny polish for both the initial protection of newly-laid/thorough cleaned floors and subsequent routine cleaning. When dry, it forms an anti-slip glossy finish. Ideal for domestic use.

### 2. Areas of Application

Vinyl and linoleum floors. Use on rubber floors is possible only under certain circumstances and should be checked before use.

### 3. Method of Application

#### Initial Protection:

Shake Floor Shine well before use. Then apply an even, thin, undiluted coat lengthways to the surface of the cleaned floor (after installation or stripped), using the Polish Applicator System or the Quick Step System. When the protective film is firm to walk on (after approximately 1 hour), repeat the procedure in the crossways direction. Allow the film to dry for at least 12 hours before the floor is walked on, better still would be overnight.

**Consumption:** 1 l = 20 m<sup>2</sup> per coat.

#### Routine Cleaning:

Dilute Floor Shine in a ratio of 1:200 (50 ml to 10 litres of water) and wet mop the floor with this solution.

**Consumption:** 1 l = 1000 m<sup>2</sup>

**Notes:** Ensure that there is sufficient ventilation but avoid exposure to drafts and strong sunlight during application and drying processes and protect the surface from dust. Turn off under-floor central heating in good time prior to use.

### 4. Technical Data

pH-level: 7.5 (concentrate)

Product code for cleaning and care products (Giscode): GE 10

Data on ingredients (EC recommendation): less than 5% non-ionic surfactants. Contains BENZISOTHIAZOLINONE, METHYLISOTHIAZOLINONE, perfumes, LIMONENE, solvents, care-components.

## Floor Shine

Floor Shine should be stored in a cool, dry place in its closed original container. Keep locked up and out of the reach of children. Protect from frost.

### 5. Quality Inspection

Certified in Germany by the Forschungs- und Prüfinstitut für Facility Management GmbH, Metzingen (FIGR)

### 6. Unit Sizes

15 x 750 ml bottles  
5 l canister

Art.-No. 2002075016  
Art.-No. 2002000501

[www.dr-schutz.com](http://www.dr-schutz.com)

*The above advice on procedure for use is based on the best of our knowledge and the latest information available on cleaning technology. For this reason, when using our quality products, no damage will be incurred to the materials to be cleaned if strict attention is paid to the instructions printed on the container and the procedure suggested by us is followed. The use to which our products are put is, however, beyond our control. It is the responsibility of the user and does not release the user from making his own checks of the products supplied by us as to their suitability for the intended procedure and purposes. The information supplied by us is therefore non-binding and cannot be used as a basis for establishing the company's liability for any damage incurred. This also includes the infringement of any rights for the protection of third parties.*

